

Sleeve Over Right Wall Clamp

SKU. SOR90

RECOMMENDATIONS:

Use only tempered safety glass.
Do not use power tools for tightening the hinge clamping plate.

MAINTENANCE GUIDELINES:

All Glaze Hardware hinges are factory greased to ensure a quiet, hassle-free installation. Suppose there is any noticeable squeaking that occurs after installation. In that case, applying a few drops of (3 in 1) multi-purpose oil to the hinge at the nylon washer/pivot location is recommended. If, for some reason, the hinge is disassembled during maintenance, use a small amount of white lithium grease to lubricate the interior hinge components. The lubricant will penetrate the hinge crevices, reducing friction and cleaning grime and buildup. The use of spray lubricants is prohibited.

Specifications:

Glass sizes: $\frac{3}{8}$ " (10mm) to $\frac{1}{2}$ " (12mm) thick-tempered safety glass
Construction: Solid brass

For $\frac{3}{8}$ " (10mm) Glass: Use One Thick Gasket On Each Side

For $\frac{1}{2}$ " (12mm) Glass: Use One Thick Gasket On Each Side

